

STANLEY RULE & LEVEL COMPANY

PRICES OF PLANE PARTS.

In several of the Planes, the Parts designated by the same name differ in form.

In these cases the corresponding Parts are given the same number; and when the Part is not shown directly opposite the number of the Plane, it will be found in another place on the plate.

Always give Plane number and Part number when ordering Cutters or Parts.

"BAILEY" IRON PLANES.

NO.	NAME OF PART	NO. OF PLANE	1	2	3	4	4½	5	5½	6	7	8
			1	2c	3c	4c	4c	5c	5c	6c	7c	8c
1A	Double Plane Iron.....		\$0 32	0 35	0 38	0 42	0 48	0 42	0 47	0 48	0 48	0 50
1	Single " ".....		18	21	23	25	29	25	28	29	29	32
2	Plane Iron Cap.....		14	14	15	17	19	17	19	19	19	18
3	Cap Screw.....		05	05	05	05	05	05	05	05	05	05
4	Lever Cap.....		25	25	25	25	25	25	25	25	25	25
5	" " Screw.....		05	05	05	05	05	05	05	05	05	05
6	Frog Complete.....		35	35	35	35	35	35	35	35	35	35
7	"Y" Adjusting Lever.....		05	05	05	05	05	05	05	05	05	05
8	Adjusting Nut.....		10	10	10	10	10	10	10	10	10	10
9	Lateral Adj. Lever.....		10	10	10	10	10	10	10	10	10	10
10	Frog Screw.....		05	05	05	05	05	05	05	05	05	05
11	Plane Handle.....		20	20	20	20	20	20	20	20	20	20
12	" Knob.....		15	15	15	15	15	15	15	15	15	15
13	Handle Bolt & Nut.....		10	10	10	10	10	10	10	10	10	10
14	Knob " ".....		10	10	10	10	10	10	10	10	10	10
15	Plane Handle Screw.....		05	05	05	05	05	05
16	Plane Bottom.....		65	85	100	100	120	120	120	165	235	285
46	Frog Adj. Screw.....		05	05	05	05	05	05	05	05	05	05




"BED ROCK" PLANES.

NO.	NAME OF PART	NO. OF PLANE	602	603	604	604½	605	605½	606	607	608	608
			"C	"C	"C	"C	"C	"C	"C	"C	"C	"C
1A	Double Plane Iron.....		\$0 35	0 38	0 42	0 48	0 42	0 47	0 48	0 48	0 50	0 50
1	Single " ".....		21	23	25	29	25	28	29	29	32	32
2	Plane Iron Cap.....		14	15	17	19	17	19	19	19	18	18
3	Cap Screw.....		05	05	05	05	05	05	05	05	05	05
4	Lever Cap.....		30	30	30	30	30	30	30	30	30	30
5	" " Screw.....		05	05	05	05	05	05	05	05	05	05
6	Frog Complete.....		50	50	50	50	50	50	50	50	50	50
7	"Y" Adjusting Lever.....		05	05	05	05	05	05	05	05	05	05
8	Adjusting Nut.....		10	10	10	10	10	10	10	10	10	10
9	Lateral Adj. Lever.....		10	10	10	10	10	10	10	10	10	10
11	Plane Handle.....		20	20	20	20	20	20	20	20	20	20
12	" Knob.....		15	15	15	15	15	15	15	15	15	15
13	Handle Bolt & Nut.....		10	10	10	10	10	10	10	10	10	10
14	Knob " ".....		10	10	10	10	10	10	10	10	10	10
15	Plane Handle Screw.....		05	05	05	05	05	05	05
16	Plane Bottom.....		1 10	1 25	1 25	1 50	1 50	1 60	2 20	3 10	3 50	3 50
44	Frog Pin.....		10	10	10	10	10	10	10	10	10	10
45	Frog Clamping Screw.....		05	05	05	05	05	05	05	05	05	05
46	Frog Adjusting Screw.....		05	05	05	05	05	05	05	05	05	05

STANLEY BLOCK PLANES.

NO.	NAME OF PART	NO. OF PLANE	100	102	103	110	120	130	131	140	203	220
			101									
1	Single Plane Iron.....		\$0 05	0 10	0 10	0 13	0 17	0 13	0 17	0 20	0 20	0 17
4	Lever Cap.....		05	10	10	10	10	10	10	15	10	10
5	" " Screw.....		05	05	05	05
6	Frog Complete.....		15	15	10	10	10
8	Adjusting Nut.....		10	10	10	10
12	Plane Knob.....		10	10	10	15	15	10	10
16	Plane Bottom.....		10	15	20	25	30	35	70	75	25	30
18	Detachable Side.....		25
19	Side Screw (Pair).....		10

STANLEY RULE & LEVEL COMPANY



STANLEY RULE & LEVEL COMPANY

PRICES OF PLANE PARTS.

In several of the Planes, the Parts designated by the same name differ in form.

In these cases the corresponding Parts are given the same number; and when the Part is not shown directly opposite the number of the Plane, it will be found in another place on the plate.

Always give Plane number and Part number when ordering Cutters or Parts.

"BAILEY" AND STANLEY BLOCK PLANES.

NO.	NAME OF PART	NO. OF PLANE	9½ 9¾	15 15½	16 17	18	19	60	60½	61	65	65½
1	Single Plane Iron.....		\$0 17	0 17	0 17	0 17	0 17	0 17	0 17	0 17	0 17	0 17
4	Lever Cap.....		10	10	15	20	20	15	10	15	15	10
5	" " Screw.....		05	05	05	05	05	05	05	05	05	05
6	Frog Complete.....		10	10	10	10	10
7	Adjusting Lever.....		05	05	05	05	05
8	Adjusting Nut.....		10	10	10	10	10	10	10	10	10	10
9	Lateral Adj. Lever.....		10	10	10	10	10
11	Plane Handle.....		25	25
16	Plane Bottom.....		70	75	75	70	75	60	60	40	75	75
21	Eccentric Plate.....		10	10	10	10	10	10	10	10	10	10
22	Finger Rest Knob.....		10	10	10	10	10	10	10	10	10	10





"BAILEY" WOOD PLANES.

NO.	NAME OF PART	NO. OF PLANE	21 22 23	24 25 35	26	27	27½	28 29	30 31	32 33 34	36	37
1A	Double Plane Iron.....		\$0 38	0 42	0 42	0 45	0 47	0 48	0 48	0 50	0 48	0 50
1	Single ".....		23	25	25	27	28	29	29	32	29	32
2	Plane Iron Cap.....		15	17	17	18	19	19	19	18	19	18
3	Cap Screw.....		05	05	05	05	05	05	05	05	05	05
4	Lever Cap.....		20	20	20	20	20	20	20	20	20	20
5	" " Screw.....		05	05	05	05	05	05	05	05	05	05
6	Frog Complete.....		30	30	30	30	30	30	30	30	30	30
7	"Y" Adjusting Lever.....		05	05	05	05	05	05	05	05	05	05
8	Adjusting Nut.....		10	10	10	10	10	10	10	10	10	10
9	Lateral Adj. Lever.....		10	10	10	10	10	10	10	10	10	10
10	Frog Screw & Bush'g ...		10	10	10	10	10	10	10	10	10	10
11	Plane Handle.....		10	10	10	10	10	10	10	10	10
12	" Knob.....		10	10	10	10	10	10	10	10	10	10
13	Handle Bolt & Nut.....		10	10	10	10	10	10	10	10	10
14	Knob " ".....		10	10	10	10	10	10	10	10	10	10
16	Plane Bottom.....		40	40	50	50	50	70	80	85	50	70
17	Top Casting.....		20	20	20	20	20	20	20	20	20	20

LEVER ADJUSTMENT AND SPECIAL PLANES.

NO.	NAME OF PART	NO. OF PLANE	104	105	122	127	129	132	135	340	62	97
1A	Double Plane Iron.....		\$0 45	0 45	0 38	0 45	0 48	0 50	0 45
1	Single ".....		27	27	23	27	28	32	27	30	30	45
2	Plane Iron Cap.....		18	18	15	18	19	18	18
3	Cap Screw.....		05	05	05	05	05	05	05
3½	Adj. Stud & Nut.....		05	05	05	05	05	05	05
4	Lever Cap.....		10	10	10	10	10	10	10	10	15	15
5	" " Screw.....		05	05	05
11	Plane Handle.....		20	20	10	10	10	10	10	30
12	" Knob.....		15	15	10	10	10	10	10	15	15	15
13	Handle Bolt & Nut.....		10	10	10	10	10	10	10	10
14	Knob " ".....		10	10	10	10	10
15	Plane Handle Screw.....		05	05	05	05
16	Plane Bottom.....		85	135	40	45	70	85	40	80	175	100
17	Top Casting.....		30	30	30	30	30
21	Eccentric Plate.....		10
22	Finger Rest Knob.....		25
39	Lever Adjustment.....		20	20	20	20	20	20	20

STANLEY RULE & LEVEL COMPANY



STANLEY RULE & LEVEL COMPANY

PRICES OF PLANE PARTS.

In several of the Planes, the Parts designated by the same name differ in form.

In these cases the corresponding parts are given the same number; and when the Part is not shown directly opposite the number of the Plane, it will be found in another place on the plate.

Always give the Plane number and Part number when ordering Cutters or Parts.

SCRAPER AND CHAMFER PLANES.

NO.	NAME OF PART	NO. OF PLANE	12 12½	12¼	112	212	85	87	56	57	72	72½
1	Single Plane Iron.....		\$0 20	0 20	0 20	0 20	0 20	0 20	0 25	0 30	0 10	0 20
4	Lever Cap.....		25	25	20	10	20	20	15	15	10	10
5	" " Screw.....								05	05	05	05
6	Frog Complete.....		60	70	35	10	30	30				
8	Adjusting Nut.....		10	10	10							
10	Frog Screw.....						05	05				
11	Plane Handle.....		50	50	20		25	20	20	10	30	30
12	" Knob.....				15	20	20	20		10	15	15
13	Handle Bolt & Nut.....				10		10	10		10	10	10
14	Knob " ".....				10	10	10	10		10	10	10
15	Plane Handle Screw.....		05	05								
16	Plane Bottom.....		1 20	80	1 20	60	1 00	80	1 00	2 50	1 50	1 50
38	Extra Wood Bottom.....		50									

RABBIT AND ROUTER PLANES.

NO.	NAME OF PART	NO. OF PLANE	90 92	93	94	196	98	99	71	71½	75	95
1	Single Plane Iron.....		\$0 30	0 30	0 30	0 25	0 20	0 20	0 30	0 30	0 10	0 20
4	Lever Cap.....		15	15	15	10	10	10			10	10
12	Plane Knob.....						15	15	15	15		
14	Knob, Bolt & Nut.....								10	10		
16	Plane Bottom.....		1 75	2 10	2 50	1 20	60	60	1 00	1 00	30	80
27	Cutter Bolt Adj. Screw.....		20	20	20							
47	Extra Attachment.....								25			
48	Collar.....								25	25		

CARRIAGE, CIRCULAR AND SCRUB PLANES.

NO.	NAME OF PART	NO. OF PLANE	10 10C	10¼	10½ " C	11 11½	113	20 20½	40	40½	51	74
1A	Double Plane Iron.....		\$0 45	0 45	0 45	0 48	0 38	0 38			0 48	0 50
1	Single " ".....		27	27	27	29	23	23	20	25	29	32
2	Plane Iron Cap.....		18	18	18	19	15	15			19	18
3	Cap Screw.....		05	05	05	05	05	05			05	05
4	Lever Cap.....		25	25	25	25	25	25	10	10	25	30
5	" " Screw.....		05	05	05	05	05	05	05	05	05	10
6	Frog Complete.....		35	35	35	35	35	35			35	
7	"Y" Adjusting Lever.....		05	05	05	05	05	05			05	
8	Adjusting Nut.....		10	10	10	10	10	10			10	
9	Lateral Adj. Lever.....		10	10	10		10	10			10	
10	Frog Screw.....		05	05	05	05	05	05			05	
11	Plane Handle.....		20	40	20	30	15		10	10	20	1 00
12	" Knob.....		15	30	15				10	10	15	
13	Handle Bolt & Nut.....		10	10	10				10	10	10	
14	Knob " ".....		10	10	10				10	10	10	
16	Plane Bottom.....		1 65	1 50	1 50	1 30	60	60	70	1 00	3 00	2 20
17	Top Casting.....						1 00	1 50				
26	Frog Seat.....							50				
35	Bottom Adj. Screw.....						50	25				
36	" " Nut.....							25				